

1-MEG MODEM CPE INSTALLATION GUIDE

- ① Connect the 1-Meg Modem to the the computer.
- ② Connect 1-Meg Modem to the telephone wall jack.
- ③ Connect the telephone to the 1-Meg Modem.
- ④ Connect the 1-Meg Modem to AC power or UPS.
- ⑤ Configure the computer.

