

# INTERACTIVE PROGRAM GUIDE

Use the *GUIDE* to see what programs are scheduled in the future.



## Interactive Program Guide Features:


**Picture in guide** - Continue to watch your program while searching the Interactive Programming Guide.

**Information** - Details about a highlighted program.

**Current Time** - Displays current time












**Program Listing** - Displays channel number, abbreviated program name, and program listing for each channel.

**Listing Date/Time** - Displays the date and time in 30 min increments for programs currently shown in the program guide.

**Favorite List** - Displays the current favorite list in use. If you press  on the remote

control more than once, the guide will rotate between *ALL*, *Subscribed*, *HD*, and your *favorites*, if you have created *favorites*.

## Navigate the Guide

1. Press  and highlight the tab, *GUIDE*. Press  . or...
2. Press  on the remote control.
3. Press  arrows to navigate through program listings by channel or press  on the remote control to move the guide forward 12 hours at a time. Press  to move the guide 12 hours back.
4. Press  to view the selected channel with the picture in guide.
5. Press  or press  to return to a full screen display.
6. Press  to display program details.
7. Press  twice to display additional details about who is starring and directed by, and what show is coming up next.

**Note:** You can only go back as far as the current day and time.