

Quick tip

Press **#** on the remote control while watching a channel to add it to a favorites list.

FAVORITES - Selecting a *Favorites* list



1. Press **GUIDE** to display the Interactive Program Guide.
2. Press **GUIDE** again to change between favorite lists. The name of the selected list will be located beneath the picture in the guide.