


FAVORITES - View a *Favorites* list



1. To view your favorites list, press **MENU** and select the tab, *Favorites*. Press **OK**.
2. Select *choose* to display the Favorites list you want to view. Press **OK**.

Delete a *Favorites* list

1. Press **MENU** then highlight and select *Favorites*. Press **OK**.
2. Select *delete* to display the Favorites list you want to delete.
3. Use the **<** **>** arrows to select yes and press **OK**.