









INFO BAR

The Info Bar is the most basic way to browse what's on other channels without missing a minute of what you're watching. The current channel number, program name, rating, and start and end times are conveniently displayed.


To browse with the info bar

1. Press  once to get detailed information for the current program.
2. Press  and  arrows to browse through other channels in numeric order.
3. Press  and  arrows to browse through future programs on a channel.
4. Press  twice to get a complete program description to include directed by, starring information, and what show is coming up next.
5. Press  to tune to the channel.



Note: The info bar will disappear after a few seconds. Press  to make it disappear immediately.

Quick tip

Press  on a program scheduled in the future to set a reminder or autotune.