








## PVR - Recording a program you're watching.

1. Press  when you are tuned to a program you want to save. Recording will begin immediately and stop at the program's scheduled end time.
2. The *RECORD* light on the digital video recorder will light up and remains on until the end of the recording.
3. Press  on your remote control while watching a program. The message, "Would you like to stop recording?" appears that enables you to stop or continue recording.
4. Select *Yes* to stop recording and press the  button on your remote. The program guide will no longer display a red dot in the grid cell for that program.

## Recording a program you're watching with extreme time at the end.







If you think a program may run too long, you can add time to the end of your recording.

1. Press  and use  to select *Edit Recording*. Press .
2. Press  to select the desired additional time.

**Note:** You can extend the recording time up to 60 mins.

## Scheduling a program or series to record from the Interactive Program Guide.

1. Press .
2. Use the  to scroll through and select a program.
3. Press . A red dot appears next to the program listing to indicate that a recording is scheduled.
4. Press  on the program that is scheduled to record. Choose *Edit Schedule* to change the frequency that the recording is scheduled. Two red dots will appear.