



Video On Demand (VOD)

Welcome to Guam Digital TV (GUdTV) Video On DEMAND (VOD), your very own 24 hour video store. Video-on-Demand is the new way to rent new movie releases or popular favorites directly from your TV. Watch what you want, when you want, without leaving the comfort of your home. Pause, rewind or fast-forward whenever you like - just like with a DVD. Even view your selection as many times as you want within the standard 24-hour viewing period.

To find out what's playing, simply tune to the VOD preview channel or visit www.gta.net.

Ordering A Movie



1. Press VOD or press . Use the arrows to select **Rentals**. Press .
2. Use arrows to browse movie categories displayed on the left side of the screen. Press to select the category you wish you view.
3. Use arrows to browse movie titles displayed on the right side of the screen. Press to select the movie you wish to view.
4. Use arrows to select **Rent** and press . Enter **PIN** (Default Pin is 0).


Clicking **Share Rental** allows other users in your home to view the movie from their Vault. If you do not want to share this rental leave this blank.


5. Use the arrows and select **Rent**. Press .
6. Enjoy your movie!

*Quick Tip: To Exit the VOD menu, press Exit on the remote control.

Finding A Purchased Movie

You can play your purchased VOD Rentals as many times as you want within the rental period. The Vault menu is where Video On Demand movie rentals are stored.



1. Press **MENU** and highlight the **VAULT** tab. Press **OK**.
2. Select **Video**. Press **OK** to view rented movies displayed on the right side of the screen.
3. Select the movie title you wish to view. Press **OK**.
4. Use the  arrows and press **OK** to choose from the following options:

Play From Last – Resume the movie from where you last left off.

Play From Start – Play the movie from the beginning

Rental Info – Display the movie title, due date (date and time movie will expire) and rating.








Play Trailer – plays movie trailer (if available).

More Info – Display a complete description about the rented movie.

Controlling Your VOD Rentals

To pause, fast-forward, rewind, or stop a program at any time, use the video control buttons on your remote.




1. Press **Pause**  to halt playback at the current point.
2. Press **Rew**  or **FF**  rewind or fast forward. Pressing **Rew**  or **FF**  repeatedly will increase the speed as you fast forward and rewind.
3. Press **Play**  to resume watching at normal speed
4. Press **Stop**  to exit the Rental menu and return to television programming

At any time you press one of the control buttons, a progress bar will appear onscreen to indicate the control function and indicates where you are in the program.

Viewing Movie Trailers

If there is a Trailer available, you can view the trailer prior to ordering a VOD movie.




1. Follow the Steps for “Ordering a movie”.
2. Select **PLAY TRAILER** and press **OK** to view the movie trailer (if available).


Quick Tip: If the Play Trailer option is not shown, there is no trailer available.



Viewing a VOD Rental Description

Most VOD Rentals have a brief description of the storyline and starring actors. Highlighting a VOD Rental will list information for that Rental in the upper right portion of the screen, including the movie title, movie rating, rental price, and rental period.



Searching VOD Rentals



1. Press search  to open the onscreen keypad.
2. Type the word or VOD title you would like to search by navigating to the letters you want to type and press **OK**.
3. Use the  arrows to select Done and press **OK**.
4. Select **Search Rentals** and press **OK**.

Sub - User VOD Rental Allowance

If you want to limit who can order Video On Demand movies, you can activate parental controls so that whoever rents Video On Demand movies has to enter a Personal Identification Number (PIN) that you create.

1. Once in the users section, navigate to the user profile that you would like to change and press **OK** .
2. Navigate to **edit** and press **OK** to change profile name.
3. Navigate to **new login** and press **OK** to change the profile name.
4. Type the user name by navigating to the letters you want to type and press **OK** to select them.
5. Navigate to **done** and press **OK** . Use **<** **>** to select new password and press **OK** to enter the new password.
6. Navigate to **done** and press **OK** .
7. Use **<** **>** to select confirm password and enter the password again.
8. Use to **<** **>** select enter **PIN** and enter the PRIMARY user's PIN (the default PIN is 0).

If there are other users in your household, monthly spending limits can be set per User and/or Sub User. For Parental Control, we recommend setting a monthly dollar limit for each Sub User allowed to rent through VOD.

A screenshot of a user settings interface. At the top, there are tabs for 'Preferences', 'Users', 'Packages', and 'Billing'. The 'Users' tab is selected. Below the tabs, there are several input fields: 'New Login', 'New Password', 'Confirm Password', and 'Theme'. To the right of these fields, there are two more fields: 'Allowance' and 'Enter PIN'. A red arrow points to the 'Allowance' field, which is currently empty. At the bottom of the screen, there are 'Submit' and 'Cancel' buttons.

Set Allowance – Used to set a limit on the dollars a user can spend on Video on Demand. This amount is renewed each month on the first of the month. (May be left blank.)