

Pay Per View (PPV)

PPV provides access to live – big ticket sports events, exciting concerts, and specialty programming all from the comfort of your couch. Unlike Video On Demand movie rentals, Pay Per View events are shown at scheduled times.

Ordering a Pay Per View event

1. Press **8 0 0** on your remote to go directly to Pay Per View, then press **OK**.

*Note: You can also press **GUIDE** and use the **Up/Down Arrows** to select Channel 800.*

2. Press the **RIGHT ARROW** button to see what PPV events are coming up in the schedule.
3. Select the program you want to order, and press **OK**. A **Program Info** screen will appear.
4. Press the **DOWN ARROW** button to select **Buy PPV**. Press **OK**.
5. Enter your **PIN** (*the default PIN is 0*).
6. Use the **arrow** buttons to select the box beside **share**. Press **OK** to check it and share the PPV with all other users; or leave it unchecked to keep your PPV purchase private.
7. Press the **DOWN ARROWS** to select **Buy** and press **OK** to purchase. Press **EXIT** to return to the channel you were watching.

NOTE:

DON'T FORGET! Once a Pay Per View is ordered, it cannot be cancelled by remote or by customer service. You will be billed and the event will air on your television set.

Pay Per View Billing

Any Pay Per View orders you place are automatically added to your monthly GTA bill. You'll find them in the "One Time Charges and Credits" section, listed by title with the date of the event and the price.

Limiting Pay Per View and Video On Demand purchases

When you use the parental locking controls, you decide who can purchase Pay Per View and Video On Demand selections by requiring a PIN (personal identification number).

Here's how to block access to Pay Per View and Video On Demand selections using your PIN:

1. Press **MENU** and use the **<>** to select **SETTINGS**. Press **OK**.
2. Enter current password (*your password is 0 unless you have changed it*), Press **OK**.
3. Go to the **Users** tab, Press **OK**.
4. Go to **Edit** (at the bottom of the screen), Press **OK**.
5. Enter current password/PIN (*default password/PIN are both set to 0*).
6. Enter in new password/PIN.
7. Confirm the new password/PIN (**make sure Enable PIN is checked**)
8. Navigate to **Submit**, Press **OK**.

To Require PIN to Rent Pay Per View and VOD.

1. Press **MENU** and use the **<>** to select **SETTINGS**. Press **OK**.
2. Enter current password (*the default password is 0*). Press **OK**.
3. Go to the **Users** tab, Press **OK**.
4. Go to **Edit** (at the bottom of the screen), Press **OK**.
5. Enter in current PIN (*default PIN is set to 0*).
6. Enter in new PIN.
7. Confirm the new PIN.
8. Navigate to **Enable PIN**, Press **OK**.
9. Navigate to **Submit**, Press **OK**.